



BMW F/G650 GS Pannier Rack

Installation Guide

A qualified, experienced motorcycle technician should install Rockfox products. If you are unsure of your ability to properly install a product, please have the product installed by your local motorcycle dealer. Rockfox takes no responsibility for damages caused by improper installation. All screws, bolts and nuts, including all replacement hardware provided by Rockfox, should be tightened to the torque specified in the OEM maintenance manual for your motorcycle. If no torque specifications are provided in the OEM maintenance manual, the following torques may be used: M6 – 9,6Nm; M8 – 23Nm; M10 – 46Nm. All screws, bolts and nuts should be checked after driving the first 50 km to ensure that all are tightened to the proper torque. Medium strength liquid thread-locker (i.e., "Loctite") should be used to secure all screws bolts and nuts.

Tools required: M8 Allen key
13 Spanner
T40 Torx Key

Contents: 1 x Left Side Rack
1 x Right Side Rack
1 x Rear Brace
1 x Pack of bolts

Left Side

Step 1



Remove the plug on the panel, by using a flat screw driver from below.

Remove the bolt from the frame.

Step 2



Fit the rear brace by installing it with underneath the tail light with the M8x20 bolt and washer.

Step 3



Fix the slide nuts to the lower bracket of the pannier rack. Do not tighten fully. Use the Hex Bolts

Step 4



Fit the top of the pannier frame using the M8x35 and washer along with the aluminium spacer.

Step 5



Insert the slide nuts into the pillion peg bracket.

Step 6



Attach the pannier frame to the rear brake with the M8x20 bolt and Nylock nut.

Repeat Step 1 - 6 for the right hand side.

As a precaution go through all bolts and nuts and tighten as needed.

Final product



Please contact us if any problems occur.

Regards
The Rockfox Team