



Honda CRF1000L Africa Twin Upper Crashbar

Installation Guide

A qualified, experienced motorcycle technician should install Rockfox products. If you are unsure of your ability to properly install a product, please have the product installed by your local motorcycle dealer. Rockfox takes no responsibility for damages caused by improper installation. All screws, bolts and nuts, including all replacement hardware provided by Rockfox, should be tightened to the torque specified in the OEM maintenance manual for your motorcycle. If no torque specifications are provided in the OEM maintenance manual, the following torques may be used: M6 – 9,6Nm; M8 – 23Nm; M10 – 46Nm. All screws, bolts and nuts should be checked after driving the first 50 km to ensure that all are tightened to the proper torque. Medium strength liquid thread-locker (i.e., "Locktite") should be used to secure all screws bolts and nuts.

Tools required: M8 Allen key
M6 Allen key
M10 Allen Key
10 Spanner
13 Spanner

Contents: 1 x Left Side Crashbar
1 x Right Side Crashbar
1 x Left Lower Bracket
1 x Right Lower Bracket
1 x Upper Bracket
1 x Left Engine Bracket
1 x Right Engine Bracket
1 x Battery Box Plate
1 x Pack Of Bolts

Step 1



Remove the toolbox by undoing the two bolts under the frame.

Remove the tools, these will be placed under the seat of the motorcycle.

Step 2



Remove the right hand side bracket and remove the long bolt running through the engine. Mind the spacers.

Step 3



Insert the left bracket with the bolt going through the motorcycle

Step 4



Attach the right bracket to the motorcycle, using the spacers from the previous bracket, along with the bolts.

Step 5



Remove the Top bolt closest to the engine, as well as the lower front bolt.

Please note the spacers.

Step 6



Fix the bottom brackets to the frame using the bolts supplied along with the 10mm Aluminium spacer on the left.

Step 7



Fix the Top Bracket using the bolts supplied. Use the 2 x 8mm Aluminium Spacers.

Step 8



Slide the rear arm of the crashbar over the bolt and screw on the supplied nut, but do not tighten fully.

Step 8



Using two bolts attach the front of the crashbar

Step 9



Fit the bottom of the crashbar to the engine brackets using the bolts supplied.

For the left side repeat steps 7, 8 and 9



Please Note the battery box bracket on the left side.

Final product



Please contact us if any problems occur

Regards
The Rockfox Team