



Honda CB500X / NX500 Pannier Rack

Installation Guide

A qualified, experienced motorcycle technician should install Rockfox products. If you are unsure of your ability to properly install a product, please have the product installed by your local motorcycle dealer. Rockfox takes no responsibility for damages caused by improper installation. All screws, bolts and nuts, including all replacement hardware provided by Rockfox, should be tightened to the torque specified in the OEM maintenance manual for your motorcycle. If no torque specifications are provided in the OEM maintenance manual, the following torques may be used: M6 – 9,6Nm; M8 – 23Nm; M10 – 46Nm. All screws, bolts and nuts should be checked after driving the first 50 km to ensure that all are tightened to the proper torque. Medium strength liquid thread-locker (i.e., "Locktite") should be used to secure all screws bolts and nuts.

Tools required:

Contents: 1 x Left Side Pannier Rack
1 x Right Side Pannier Rack
1 x Bolt Pack

Left Side Step 1



Remove the rear grab handles by removing the marked bolts.

Step 2



Remove the pillion foot peg

Step 3



Attach the Pannier Rack using the 20x4x7 mm spacer and the supplied M6 bolt on the front bracket and the 20x8x9 spacer on the rear bracket, along with the OEM bolt.

Step 4



Fit the pannier rack behind the footpeg using the OEM bolts and the 20x4x9 spacer on the front of the pillion footpegs.

Right Side : Repeat Steps 1 to 4

Step 5



Fit the rear brace between the two pannier racks using the M8x20 bolts.

Tighten all bolts.

Final product



Please contact us if any problems occur or if bars are difficult to fit.

Regards
The Rockfox Team