



BMW R1300GS Bashplate

Installation Guide

A qualified, experienced motorcycle technician should install Rockfox products. If you are unsure of your ability to properly install a product, please have the product installed by your local motorcycle dealer. Rockfox takes no responsibility for damages caused by improper installation. All screws, bolts and nuts, including all replacement hardware provided by Rockfox, should be tightened to the torque specified in the OEM maintenance manual for your motorcycle. If no torque specifications are provided in the OEM maintenance manual, the following torques may be used: M6 – 9,6Nm; M8 – 23Nm; M10 – 46Nm. All screws, bolts and nuts should be checked after driving the first 50 km to ensure that all are tightened to the proper torque. Medium strength liquid thread-locker (i.e., "Locktite") should be used to secure all screws bolts and nuts.

Tools needed

4mm Allen Key
T40 Torx

Step 1

Remove the OEM Bashplate by undoing the 4 bolts on the bike

Step 2

Fit the Rockfox Bashplate with the 2 M6x40 bolts in the front and the 2 M6x30 bolts in the back

Final Product



Please contact us if any problems occur or if bars are difficult to fit.

Regards
The Rockfox Team