



BMW R1200GS AC Bashplate

Installation Guide

A qualified, experienced motorcycle technician should install Rockfox products. If you are unsure of your ability to properly install a product, please have the product installed by your local motorcycle dealer. Rockfox takes no responsibility for damages caused by improper installation. All screws, bolts and nuts, including all replacement hardware provided by Rockfox, should be tightened to the torque specified in the OEM maintenance manual for your motorcycle. If no torque specifications are provided in the OEM maintenance manual, the following torques may be used: M6 – 9,6Nm; M8 – 23Nm; M10 – 46Nm. All screws, bolts and nuts should be checked after driving the first 50 km to ensure that all are tightened to the proper torque. Medium strength liquid thread-locker (i.e., "Locktite") should be used to secure all screws bolts and nuts.

Colour and finish may vary from photos.

Step 1



Remove the old bashplate by unscrewing the four mounting bolts.

NOTE: Brackets may differ between year models.

Step 2



Attach the Rockfox bashplate to the remaining brackets.

NOTE: If the left front bolt is a M8 hex nut this must be replaced by a M8 Allencap of similar length

Step 3



Attach the Norma Clamp to the bar, which runs just above the catalytic converter, so that the flat side is facing forwards

Step 4



Attach the rear brace to the Norma clamps flat side. Making sure the bottom bend is facing inwards

Step 5



Attach the brace to the bashplate with the supplied countersunk screw.

Tighten All bolts now.

As a precaution go through all bolts and nuts and tighten as needed.

Final product



Please contact us if any problem or if bars are difficult to fit.

Regards
The Rockfox Team